

Turning the Deva on: Small black slider switch on left side

Setting Timecode: Touch TC display on touch screen. This will take you to the time code settings page.

Bit depth and Sampling Rate: From Main Menu select Deva Setup and page selection buttons for these items are there, labeled and self evident.

Setting gain structure: From Main Menu, select Input Control. Then select individual channels for input setting choices, e.g., mic/line, 48v phantom, low cut, delay and trim.

You must format all DVD-Rams prior to mirroring. (Fat 32/UDF)
Main Menu/My Deva/Int DVD/Mirror Drive 1/ select bit depth, file type, tracks to mirror, and format.

Arming tracks for record: Arrow key/select track from Home Screen

Entering Metadata: STN/enter individual fields,

Track naming: Main Menu/My Deva/Meters/Meter Labels

Playback: from HD- press play for last take recorded. To select segment, press CUE button for cue screen.

Editing/correcting metadata: Turn off mirroring, reset to segment in question, enter new/corrected info, reset "mirror from" segment number to include the rewrite, turn mirroring on

Although occasionally reported, I have never experienced machine lock up on a Deva V

Check out the free downloadable manual for multiple access/shortcuts to the various menu screens